



## MEASURING UP FOR A INSECT PANEL DOOR SCREEN

Firstly measure the width of the aperture\*, plus any bevelled edges on the window frame.

- For mounting inside the aperture\* add at least 25mm to the width on each side, to allow for an overlap of the mesh panels
- For mounting outside of the aperture\*, allow a wider overlap of 50mm on each side.

Then measure the height (drop) from the top of the door frame to the threshold or floor. Deduct 10mm to allow clearance of the mesh panels

Our insect panel door screens are made to measure, as per your given dimensions

- *Aperture – refers to the door opening, the area which allows light into the room*