

RETENSIONING OF SOLARGLIDE SUNSCREENS

On occasions **SOLARGLIDE** sunscreens can become detensioned. Following these simple instructions can retension them again quickly and easily.

1. Place the cassette vertically onto a flat surface, with the right hand side of the blind cassette facing downwards (the right hand side black cassette end cap should be flat to the surface)
2. The opposite end of the cassette profile (left hand side) should now be visible facing upwards
3. Carefully remove all three fixing screws with a cross point screwdriver whilst tightly holding the black (cassette) end cap in place. It may be best to ask for assistance from another person at this stage.

CAUTION – if the end cap is removed or not held securely in place then the blind will fully detension.

4. Whilst applying downward pressure on the end cap to keep it flush to the cassette, slowly rotate the end cap clockwise until resistance is felt. This resistance means that the blind spring is beginning to retension. Once you start to feel the resistance take a further three turns.
5. Replace the three screws into place whilst continuing to apply downward pressure on the end cap, please note that if you let go at this point the blind will spring back to the position you started at and you will have to start the whole procedure again.
6. When the screws are tightened the blind should then be fully retensioned and ready for operation (see figure 1 below)

To replace damaged end caps firstly replace the right hand end cap – then follow the above procedures for replacing the left hand side end cap and retensioning of screens

